

204616

BENCH

ASSEMBLY INSTRUCTIONS



www.coastercompany.com

3e. 1515 / 05 / 17 SU

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately
- 2. This product is for home use only and not intended for commercial establishment.






ASSEMBLY TIME | 15 MINUTES

PARTS IDENTIFICATION


A.



TOP

1 PC


В.



LEG (WITH 'B' LABEL)

2 PCS


C.



LEG (WITH 'C' LABEL)

2 PCS

D.



STRETCHER

1 PC

HARDWARE IDENTIFICATION

1.

BOLT

8 PCS

2.



LOCK WASHER

8 PCS

3.



FLAT WASHER

8 PCS

4.



Z - ALLEN WRENCH

1 PC

5.




SCREW


4 PCS

NOTE: PHILLIPS HEAD SCREW DRIVER IS REQUIRED IN THE ASSEMBLY PROCESS; HOWEVER MANUFACTURER DOES NOT PROVIDE THIS ITEM.


COASTER.

www.coastercompany.com





ASSEMBLY INSTRUCTIONS



ASSEMBLY COMPLETED

