

**COASTER**®  
*Fine Furniture*

**504401**

SOFA

**ASSEMBLY INSTRUCTION  
COASTER FINE FURNITURE**



[www.coastercompany.com](http://www.coastercompany.com)

**ASSEMBLY INSTRUCTIONS**











**ASSEMBLY TIPS:**

1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



**Warning!**

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment


(A)		<b>SEAT</b>	<b>1PC</b>
(B)		<b>LEFT ARM FACING BACK</b>	<b>1PC</b>
(C)		<b>MIDDLE BACK</b>	<b>1PC</b>
(D)		<b>RIGHT ARM FACING BACK</b>	<b>1PC</b>
(E)		<b>MASTER COLOR PILLOW</b>	<b>2PCS</b>
(F)		<b>PATTERN COLOR PILLOW</b>	<b>2PCS</b>
(G)		<b>LUMBAR PILLOW</b>	<b>1PC</b>
(H)		<b>BACK LEG</b>	<b>2PCS</b>
(I)		<b>FRONT LEG</b>	<b>2PCS</b>
(J)		<b>MIDDLE LEG</b>	<b>1PC</b>

**Z**


**HARDWARE PACKAGE**

(1)		<b>PLASTIC WASHER</b>	<b>5PCS</b>
-----	---	-----------------------	-------------


STEP 1




STEP 2




STEP 3



STEP 4



STEP 5



STEP 6

