

ASSEMBLY INSTRUCTION

COASTER FINE FURNITURE



www.coastercompany.com

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:


1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



Warning!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment


(A)



SOFA

1PC

(B)



CUSHION

2PCS


(C)



LUMBAR PILLOW

2PCS

(D)



LEG

4PCS

Z

HARDWARE PACKAGE

(1)




PLASTIC WASHER


4PCS

IT NEEDS TWO PERSONS AND TAKES ABOUT TWENTY MINUTES TO ASSEMBLE THE ITEM.


STEP 1




STEP 2



STEP 3



STEP 4



STEP 5

