

COASTER®

Fine Furniture

603021

MOTION SOFA WITH DROP DOWN TABLE & DRAWER

ASSEMBLY INSTRUCTION COASTER FINE FURNITURE



www.coastercompany.com

Assembly Instruction

ASSEMBLY TIPS:







- 1: Remove hardware from box and sort by size
- 2: Please check to see that all hardware and parts are present to prior start of assembly.
- 3: Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly




Warning

- 1: Don't attempt to repair or modify parts that are broken or defective please contact the store immediately
- 2: This product is for home use only and not intended for commercial establishment

PARTS IDENTIFICATION:


A. LEFT EAR		1PC
B. RIGHT EAR		1PC
C. LEFT REST		1PC
D. MIDDLE REST		1PC
E. RIGHT REST		1PC
F. BASE		1PC

STEP1



STEP2

Align the male and female brackets on the seat bases, ears, and rests. Once aligned push firmly down until a click sound is heard.



STEP3

