

**COASTER**<sup>®</sup>  
FINE FURNITURE

**800494**

**CHAIR**

---

**ASSEMBLY INSTRUCTION  
COASTER FINE FURNITURE**



**[www.coastercompany.com](http://www.coastercompany.com)**

REVISION 0: 2011/07/15

REVISION 1: 2011/11/01

# Assembly Instruction

**ASSEMBLY TIPS:**


1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




**Warning !**

1. Don't attempt to repair or modify parts that are broken or defective .Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

**PARTS IDENTIFICATION**



FRAME




**Z HARDWARE PACKAGE**

NO	DESCRIPTION	FIGURE	Q'TY
1	ALLEN WRENCH		1PC
2	BOLT		8PCS
3	FLAT WASHER		8PCS
4	LOCK WASHER		8PCS

STEP1

Align and fasten cushion with frame to legs using bolt, lock washer and flat washer with allen wrench.



COMPLETE

