



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

900240

ACCENT CHAIR WITH OTTOMAN

REVISION 1: 06/06/2019

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM: **900240**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


10 MINUTES

PARTS IDENTIFICATION


A	SEAT AND BACK		1PC	C	LEG FOR CHAIR		4PCS
B	OTTOMAN		1PC	D	LEG FOR OTTOMAN		4PCS

ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2



STEP 3



STEP 4

