



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

602303P
POWER RECLINER

REVISION 1:08/21/2018
REVISION 2:07/15/2019

COASTERFURNITURE.COM

ITEM: 602303P
ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME PER UNIT	20 MINUTES
------------------------	------------

PARTS IDENTIFICATION


A



BASE

1 PC

B




BACK

1 PC


ITEM: 602303P
ASSEMBLY INSTRUCTIONS





STEP1



STEP2




STEP3



ITEM: 602303P
ASSEMBLY INSTRUCTIONS



SHOW1



SHOW2

