



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

650163
SWIVEL ROCKER

REVISION 1:07/16/2014
REVISION 2:07/15/2019

COASTERFURNITURE.COM

PAGE 1 OF 3

ITEM: 650163
ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME PER UNIT | 10 MINUTES


PARTS IDENTIFICATION

A		BASE	1 PC
B		BACK REST	1 PC
C		LEFT BACK EAR	1 PC
D		RIGHT BACK EAR	1 PC


ITEM: 650163
ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2



STEP 3

